


Parts Identification / Pengenalan Bahagian



- 1. Oscillation Knob / Tombol Ayunan
- 2. Motor Body / Badan Motor
- 3. Rear Fan Guard / Penghadang Kipas Belakang
- 4. Fan Guard Lock Screw / Skru Pengunci Penghadang Kipas
- 5. Fan Blade Lock Screw / Skru Pengunci Bilah Kipas
- 6. Front Fan Guard / Penghadang Kipas Hadapan
- 7. Fan Guard Ornament / Hiasan penghadang Kipas
- 8. Speed Regulator / Pengawal Kelajuan
- 9. Fan Blade/ Bilah Kipas

Specifications / Spesifikasi


Size Saiz	Model	Voltage Voltag	Power Kuasa	Speed / Kelajuan (RPM)			Air Delivery Kelajuan Angin
				Low	Medium	High	
18"	WF 1811	240V~50Hz	124W	990	1170	1320	115 m³/min 4061 cfm

*Specifications are subject to change without prior notice. *Spesifikasi boleh ditukar tanpa sebarang notis.


Caution and Cleaning

1. For safety precaution, please turn off the switch and unplug the socket before cleaning the fan blade and body.
2. Do not use gasoline or any chemical liquid for cleaning, to avoid from discoloration.
3. Do not use in high temperature and humid areas.
4. Do not insert fingers or other objects into the fan guard.
5. Use a dry cloth to clean the fan blade
6. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
8. Do not operate the fan without a fan blade or with a broken/ bent fan blade.
9. Do not immerse motor body or any parts of the fan inside the water or other liquids.
10. Use this fan with specified voltage as stated on the rating sticker. Before connecting fan to the AC mains, make sure the voltage specified corresponds to the AC supply to your house.
11. The ventilation holes of rear motor cover must be free of dust & dirt. Please use a soft cloth or vacuum cleaner to clean it frequently.


Installation Guide



1. Fix the wall mount base to the wall with heavy duty concrete anchor provided.



2. Attach the rear fan guard by fastening the 4 fan guard lock screws to the motor body.




3. Insert the fan blade onto the motor shaft. Lock the fan blade to the motor shaft by tightening the fan blade lock screw.

Installation Guide



4. Hold the front guard with logo in upright position and attach it to the rear guard. Secure the two guards by fastening the clip.




5. Adjust the regulator switch to select the desired speed.
 - 0 - Off
 - 1 - Low speed
 - 2 - Medium speed
 - 3 - High speed

Operating Instructions


1. Ensure that the fan is fixed at a height that is more than 2.3m from the floor
2. Please use the fan with the specified voltage of 240V~50Hz as stated on the rating sticker. Before connecting the fan, make sure the voltage specified corresponds to the main voltage in your home.
3. Select the desired speed by using speed selection on the speed regulator.

1. Untuk keselamatan, sila matikan suis dan cabut palam sebelum membersihkan bilah dan badan kipas.
2. Jangan gunakan minyak atau sebarang cecair kimia untuk pembersihan bagi mengelakkan warna luntur.
3. Jangan gunakan di tempat yang bersuhu tinggi dan lembap.
4. Jangan masukkan jari atau objek kimia ke dalam penghadang kipas.
5. Gunakan kain yang kering untuk membersihkan bilah kipas.
6. Jika talikod telah rosak, ia mesti diganti oleh pengilang, wakil servis atau orang yang berkelayakan untuk mengelakan sebarang bahaya.
7. Perkakas ini bukan untuk digunakan oleh orang (termasuk kanak-kanak) yang kurang upaya fizikal, deria atau kecacatan mental, atau kurang pengalaman dan pengetahuan, melainkan mereka diberi perhatian atau tunjuk ajar berkaitan penggunaan perkakas oleh orang yang bertanggungjawab untuk keselamatan mereka. Kanak-kanak haruslah diperhatikan untuk memastikan mereka tidak bermain dengan perkakas ini.
8. Jangan gunakan kipas tanpa bilah, bilah yang rosak atau bengkok.
9. Jangan rendamkan badan motor atau sebarang bahagian kipas ini di dalam air atau cecair lain.
10. Gunakan kipas ini dengan voltan yang telah ditentukan seperti yang tercatat di atas pelekat kadar sebelum menyambung kipas ke bekalan AC, pastikan voltan yang ditentukan sama dengan bekalan AC ke rumah anda.
11. Lubang pengudaraan pada penutup motor belakang mestilah bebas daripada habuk & kotoran. Sila gunakan kain lembut atau vakum untuk membersihkannya.


Panduan Pemasangan



1. Pasangkan tapak penyokong dinding dengan Sauh Konkrit tugas berat disediakan.




2. Pasangkan penghadang belakang kipas dengan mengunci 4 skru pengunci penghadang kipas pada badan motor.



3. Masukkan bilah kipas pada Shaf Motor. Kuncikan bilah kipas pada Shaf Motor dengan cara mengetatkan skru pengunci bilah kipas.

Panduan Pemasangan



5. Laraskan suis Pengawal untuk memilih kelajuan yang dikehendaki.

- 0 - Tutup
- 1 - Kelajuan rendah
- 2 - Kelajuan sederhana
- 3 - Kelajuan tinggi

4. Pegang penghadang hadapan dengan logo pada kedudukan yang betul dan pasangkan pada penghadang belakang. Ketaikan kedua-dua penghadang dengan klip.

KHIND
Delivering Happiness



••• 18" Industrial Wall Fan / Kipas Dinding Industri 18"

Instruction Manual / Buku Panduan

Important / Mustahak

Please read this manual carefully before operating this product. Keep this manual handy for future reference.
Sila baca buku panduan ini dengan teliti sebelum menggunakan produk ini. Simpanlah untuk rujukan masa depan.



This manual is also available online